Orange Sydney
Menu map

Contents

	Page
Files	3
Contacts	4
Application	5
Calls	6
Messaging	7
Media	9
Tools	11
Settings	12
Profiles	14
Camera	15
Services	16
WiFi	17

Files

Level 1 Menu	Level 2 Menu	Level 3 Menu	Level 4 Menu	Level 5 Menu	Level 6 Menu
Total					
Free					
Options	Open	List of files			
		New	Folder name		
			Options	Done	
				Cancel	
				Insert symbol	
				Input method	
				Input method options	Set Zi
					New Zi word
					Advanced settings
			Back		
		Back			
	Back				

Contacts

Level 1 Menu	Level 2 Menu	Level 3 Menu	Level 4 Menu	Level 5 Menu	Level 6 Menu
Contacts	List of contacts				
	Enter text to search				
	Call				
	Message				
	Add new comntact	To SIM			
		To Phone	Enter details	OK	
				Back	
	Options	View			
		Send message			
		Call			
		IP dial			
		Edit			
		Delete			
		Copy			
		Move			
		Send business card			
		Add to blacklist			
		Mark several			
		Phonebook settings	Preferred storage		
			Speed dial		
			My number		
			Extra numbers		
			Memory status		
			Copy contacts		
			Move contacts		
			Delete all contacts		
			OK		
			Back		
	Back				
Groups	List of groups				
	Options	Add group			
		Phonebook settings	Preferred storage		
			Speed dial		
			My number		
			Extra numbers		
			Memory status		
			Copy contacts		
			Move contacts		
			Delete all contacts		
			OK		
			Back		
	Back				

Application

Level 1 Menu	Level 2 Menu	Level 3 Menu	Level 4 Menu	Level 5 Menu	Level 6 Menu
Facebook	Launches App	Enter login details			
Twitter	Launches App	Enter login details			
Options	Launch				
	Information				
	Settings	Ask for permission	Select from list		
		Save			
		Cancel			

Calls

Level 1 Menu	Level 2 Menu	Level 3 Menu	Level 4 Menu	Level 5 Menu	Level 6 Menu
Csll history	List of calls				
	Call				
	Send message				
	Options	View			
		Call			
		Send message			
		Add to blacklist			
		Edit before call			
		Delete			
		Delete all			
		Advanced	Call timers		
			Call cost		
			Text msg. counter		
			GPRS counter		
Call settings	Caller ID	Set by network			
		Hide ID			
		Send ID			
	Call waiting	Activate			
		Deactivate			
		Query status			
	Call divert	Divert all voice calls			
		Divert if unreachable			
		Divert if no answer			
		Divert if busy			
		Divert all data calls			
		Cancel all diverts			
	Call barring	Outgoing calls			
		Incoming calls			
		Cancel all diverts			
		Change barring password			
	Group list				
	Adance settings	Blacklist			
		Auto redial			
		IP dial			
		Background sound			
		Call time display			
		Call time reminder			
		Auto quick end			
		Reject by SMS			
		Connect notice			
		Answer mode			

Messaging

Level 1 Menu	Level 2 Menu	Level 3 Menu	Level 4 Menu	Level 5 Menu	Level 6 Menu
Write message	Input text				
	Send SMS	Enter recipient			
		Add from phonebook			
	Insert	My pictures			
		Take picture			
		My sounds			
		Record sound			
		My videos			
		Record video			
		Insert text template			
		Insert attachment			
		Insert Contact number			
		Insert contact name			
		Insert bookmark			
	Options	Send to			
		Insert symbol	Select from list		
		Input method	Select from list		
		Input method options	Select from list		
		Add picture	My Pictures		
			Take picture		
		Add sound	My sounds		
			Record sound		
		Add video	My videos		
			Record video		
		Add subject			
		Slide options	Add slide behind		
			Add slide before		
		Switch to MMS			
		Advanced	Insert text template		
			Insert attachment		
			Insert Contact number		
			Insert contact name		
			Insert bookmark		
		Save			
		Details			
Inbox	List of messages				
	Reply				
	Forward				
	Delete				
Drafts					
Outbox					
Sent messages					
Delete messages					
Email	Follow setup instructions				
Broadcast messages					
Templates					
Message settings	Text message	Profile settings	Profile 1		
			Profile 2	Options	Activate
					Edit
		Voicemail server	Ensure +447973100123 is showing		
		Common settings	Deleivery report	Tick/Untick	
			Reply path	Tick/Untick	
			Save sent message	Tick/Untick	
		Memory status	SIM		
			Phone		
		Preferred storage	SIM		
			Phone		
		Preferred connection	Prefer GPRS		
			Prefer GSM		
			GSM only		

	Multimedia message	Data account	Primary	Select from list	
			Secondary	Select from list	
		Common settings	Compose	Slide time	
				Creation mode	Select from list
				Picture resizing	Select from list
				Auto signature	On
					Off
				Signature	Enter text
			Sending	Validity period	Select from list
				Delivery report	On
					Off
				Read report	On
					Off
				Priority	Select from list
				Delivery time	Select from list
				Send and save	
			Retrieval	Home network	Select from list
				Roaming	Select from list
				Filters	Anonymous
					Advertisement
				Read report	Select from list
				Delivery report	On
					Off
			Preferred storage	Phone	
				Memory card	
			Memory Status	Phone	
				Memory card	
	Service message	Enable push	Select from list		
		Enable service loading			
		Enable white list			
		White list			

Media

Level 1 Menu	Level 2 Menu	Level 3 Menu	Level 4 Menu	Level 5 Menu	Level 6 Menu
Image viewer	Select image				
	Options	Browse style	List style		
			Matrix style		
		Storage	Phone	Toal	
				Free	
			Memory card	Toal	
				Free	
Media player	Now playing				
	All songs				
	Artists				
	Albums				
	Genres				
	Playlists				
	All videos				
	Refresh library				
	Settings	Player settings	Shuffle	On	
				Off	
			Repeat	On	
				Off	
			Sound effects	On	
				Off	
		Audio settings	Audio play speed	Select from list	
			Display style	Select from list	
		Bluetooth settings	BT stereo output	On	
				Off	
			BT stereo headset		
	Reset library				
Photo editor	Photo artist	Select from file			
		Capture from camera			
		Reszie image			
	Image tiles	2 image tiles			
		4 image tiles			
		9 image tiles			
Sound recorder	Back				
	Forward				
	Play				
	Record				
	Stop				
	Options	New record			
		List style			
		Settings	Storage		
			File format		
			Audio quality		
FM radio	Auto search back				
	Manual search back				
	Manual search forward				
	Auto search forward				
	Record				
	Power off				
	Options	Channel list			
		Manual input			
		Auto search			
		Settings	Loudspeaker	On	
				Off	
			Record format	Select from list	
			Audio quality	Select from list	
			Record storage	Select from list	

			Channel effect	Select from list	

Tools

Level 1 Menu	Level 2 Menu	Level 3 Menu	Level 4 Menu	Level 5 Menu	Level 6 Menu
Calendar	Select date				
	Options	View			
		View all			
		Add event	Type	Start date	
				Start time	
				End Date	
				End time	
				Subject	
				Alarm	On
					Off
				Alarm date	
				Alarm time	
				Repeat	Select from list
				Repeat days	
				Location	
				Details	
				OK	
		Delete event			
		Jumpt to date			
		Go to today			
		Go to weekly view			
Tasks	List of current tasks				
	Options	View			
		Add	Enter details		
			OK		
		Edit			
		Search			
		Delete			
		Delete overdue			
		Delete all			
		Jump to date			
		View uncompleted			
		Send vCalendar			
		Save as file			
Alarm	Tap an alarm to edit	On/Off			
		Time			
		Repeat			
		Days			
		Alarm tone			
World Clock					
Notes	Add				
	Back				
Calculator					
Currency converter					

Settings

Level 1 Menu	Level 2 Menu	Level 3 Menu	Level 4 Menu	Level 5 Menu	Level 6 Menu
Phone settings	Time and date	Set home city			
		Set foreign city			
		Set time/date	Time		
			Date		
			Daylight saving	On	
				Off	
		Set format	Time		
			Date		
			Date seperator		
		Update with time zone			
	Schedule power on/off				
	Language	select from list			
	Input method	select from list			
	Encoding	select from list			
	Display	Wallpaper	System		
			User defined		
		Screen saver	settings	Status	
				Waiting	
			Select		
		Power on display	System		
			User defined		
		Power off display	System		
			User defined		
		Main menu effect	Select from list		
	Greeting text	Status			
		Greeting text			
	Auto update time	Off			
		First confirm			
		On			
	Flight mode	Normal mode			
		Flight mode			
		Query when power on			
	Misc settings	LCD Backlight	Brightness		
			Time		
	Calibration				
Network settings	Network selection	New search			
		Select network			
		Selection mode			
	Preferences	select from list			
	Preferred mode	GSM only			
		WLAN only			
		GSM preferred			
		WLAN preferred			
	GPRS connection	When needed			
		Always			
Security settings	SIM lock				
	Phone lock				
	Auto keypad lock				
	Change password				
	Certificate manager				
Connectivity	Bluetooth	Power			
		Visibility			
		My device			
		search audio device			
		My name			
		Advanced	Audio path		

			Storage		
			Sharing permission		
			My address		
	Conn. Management				
	Data account	Select account			
Restore factory settings					

Profiles

Level 1 Menu	Level 2 Menu	Level 3 Menu	Level 4 Menu	Level 5 Menu	Level 6 Menu
Select profile	Options	Activate			
		Customise	Alert type		
			Ring type		
			Incoming call		
			Ringtone volume		
			Message		
			Message volume		
			Keytone		
			Keytone volume		
			System alert		
		Reset			

Camera

Level 1 Menu	Level 2 Menu	Level 3 Menu	Level 4 Menu	Level 5 Menu	Level 6 Menu
Capture					
Settings	EV				
	Switch to	Photo album			
		Video recorder			
		Capture mode	Normal		
			Continuous shot		
			Burst shot sel.		
			Smile shot		
		Scene mode	Auto		
			Night		
		Image size	VGA		
			1MP		
			2MP		
			3MP		
		Face detection	Off		
			On		
		Self timer	Off		
			5 sec		
			10 sec		
		White balance	Auto		
			Daylight		
			Fluorescent		
			Cloudy		
			Incandescent		
		Effects	Normal		
			Grayscale		
			Sepia		
			Sepia blue		
			Colour invert		
			Sketch		
		Adv settings	Storage	Phone	
				Memory card	
			Image quality	Fine	
				Good	
				Normal	
			Shutter sound	select from list	
			Anti flicker	select from list	
			Restore default		

Services

Level 1 Menu	Level 2 Menu	Level 3 Menu	Level 4 Menu	Level 5 Menu	Level 6 Menu
Orange plus	Call orange				
	Information				
Internet service	Homepage				
	Bookmarks				
	Input address				
	Last web address				
	Recent pages				
	Stored pages				
	settings	Homepage			
		Data account			
		Browser options			
		Preferences			
		Security settings			
		Restore browser settings			
License manager	Licence list				
	Status				
	Advance				

WiFi

Level 1 Menu	Level 2 Menu	Level 3 Menu	Level 4 Menu	Level 5 Menu	Level 6 Menu
Select network from list	Connect				
	Add				
	Define access point				
	WLAN status				
	Disable WLAN				
	Refresh				